


## HIKVISION Changing the Date & Time



Click on menu



Click on Configuration



Click on System Time/System Date



Click APPLY on the bottom RIGHT